


## ROOFS WITHOUT THERMAL INSULATION – TERRACE, PAVERS ON STANDS, BITUMEN SHEETS



- 1 SUPPORT CONSTRUCTION
- 2 CONCRETE GRAVITY LAYER
- 3 BITUMEN SHEET WATERPROOFING  
NON SOLID GLUED OR LAID LOOSE
- 4 BITUMEN SHEET WATERPROOFING
- 5 PAVERS ON STANDS
- 6a DRAIN BODY HL616HK  
WITH BITUMEN MEMBRANE  $\varnothing 500$  mm,
- 6b FROST-PROOF FLAP HL0606.3E
- 7 FLAT LEAF STRAINER HL191  
LEAF STRAINER HL190
- 8 ASSEMBLY FOAM
- 9 DOWNPIPE

### NOTICE:

TO HEAT THE DRAIN, YOU MAY USE HEATING KIT HL609 WITH SELF-REGULATING HEAT SOURCE 36W/230V. (THE HEATING TAPE MUST BE WRAPPED AROUND THE DRAIN BODY BEFORE INSTALLATION).

RECOMMENDED BOREHOLE DIAMETER IS  $\varnothing 290$ mm, OR:  $\square 290 \times 290$ mm  
DURING INSTALLATION TAKE CARE, THAT THE FLANGE POSITION IS ON THE LOWEST LEVEL OF DRAINAGE. WE RECOMMEND, TO SITE IT APPR. 1cm BELOW THE SCREED.  
TO AVOID CONDENSATE WATER TAKE CARE OF THERMAL INSULATION ON THE CONSTRUCTION SITE.

112131Y